




右向插掃刀 Right Hand Groove and Turn

無 斷屑槽 NO Breaker






型 號 EDP NO.	W	θ°	r	L2	X21	NCO2	HCO3	適用刀架 HOLDER NO.
75.6330-00 NB	4.0	35°	0.0	8.5	●	●		CS789R****-63
75.6330-01 NB	4.0		0.1					
75.6330-02 NB	4.0		0.2					
75.8440-00 NB	4.0	35°	0.0	8.5	●	●		CS668R****-84
75.8440-01 NB	4.0		0.1					
75.8440-02 NB	4.0		0.2					

無"●"標示者為訂製品。Without "●" marking means custom products.

有"●"標示者為在庫品。With "●" marking means items in stock.




右向插掃刀 Right Hand Groove And Turn

MA 斷屑槽 MA Breaker



型 號 EDP NO.	W	θ°	r	L2	KC	NA01	HC83	適用刀架 HOLDER NO.
774.10-01 MA	1.0		0.1	2.0	●	●		CS900R****84
774.15-01 MA	1.5		0.1	3.0	●	●		
774.15-02 MA	1.5		0.2					
774.20-01 MA	2.0		0.1	4.0	●	●		
774.20-02 MA	2.0		0.2		●	●		
774.25-01 MA	2.5		0.1	6.0				
774.25-02 MA	2.5		0.2		●	●		
774.30-01 MA	3.0		0.1	8.0				
774.30-02 MA	3.0		0.2		●	●		

無 斷屑槽 NO Breaker



型 號 EDP NO.	W	θ°	r1	L2	KC	NA01	HC83	適用刀架 HOLDER NO.
774.10-01 NB	1.0		0.1	2.0	●	●		CS900R****84
774.15-01 NB	1.5		0.1	3.0	●	●		
774.15-02 NB	1.5		0.2					
774.20-01 NB	2.0		0.1	4.0	●	●		
774.20-02 NB	2.0		0.2		●	●		
774.25-01 NB	2.5		0.1	6.0				
774.25-02 NB	2.5		0.2		●	●		
774.30-01 NB	3.0		0.1	8.0				
774.30-02 NB	3.0		0.2		●	●		

無"●"標示者為訂製品。Without "●" marking means custom products.
有"●"標示者為在庫品。With "●" marking means items in stock.